



Tel: 855-757-2776
scorpionsp.com
support@scorpionsp.com
August 2022

THE ORIGINAL (OG) WEARABLE SCORPION: SAMUNG ACTIVE2 INSTALLATION INSTRUCTIONS

ORIGINAL WEARABLE SCORPION: SAMSUNG ACTIVE2 INSTALLATION VIDEO



IMPORTANT PLEASE READ BEFORE INSTALLING

Before installing, use supplied blue key to unlock Scorpion axle. Unlock by turning counter clockwise.



1. Start by mounting the base to the fixture. Install the under counter plate and wingnuts until tightened.



NOTE: Do not over tighten

2. Feed charging cable through the base and through the charging cable notch.



3. Take the top, and use the security key on the axle of the Scorpion and turn counter clockwise to ensure that the legs are fully extended. Once the legs are fully extended, insert the charging puck.



4. Place the watch into the Scorpion, and use the security key to tighten the legs to the watch, by turning clockwise until the legs are snug against the watch.



NOTE: Leveling plate may need to be lowered in order to fit watch in. (see step 7) You may need to insert watch at slight angle.

5. Align the watch with the center of the leveling plate.



6. Tighten the side legs of the Scorpion until they slightly touch the side of the device by inserting the security key into the axle and rotate clockwise.



NOTE: Do not over tighten

7. Raise the leveling plate by inserting the security key into the leveling plate studs. Switch back and fourth between the studs to ensure equal pressure.



NOTE: Alternate 3 turns per stud until plate is raised

8. After securing the leveling plate, go back and tighten the side legs. There will no longer be a gap between the screen and legs when the leveling plate has been properly raised. Tuck watch band in designated slot.



***IMPORTANT* MUST LOCK AXLE TO FULLY SECURE**

9. To lock the axle, insert the security key into the center of the Scorpion body located on the back side of the device. Turn the security key clockwise to tighten the screw and lock the axle into place.



TO INSTALL AS LOCK DOWN

1. To lock down, place the installed device into the receiver. Press the lock in to secure and double check that the Scorpion is locked into place.

